


# Lab 8 – Sensors – Basic Camera Operations



# Lab's Objectives

- 1) To learn about image color sorting by finding red, blue, and green objects.
- 2) To learn a way to center a red, blue, and green object.
- 3) To learn about background subtraction which can be used to find an object of any color.
- 4) To learn about converting pixels to centimeters.
- 5) To learn about a way to reduce image noise.
- 6) To learn about converting the camera frame of reference to the base frame of reference with the use of Homogenous matrices.

# Agenda



- Expected Demonstrations
- Expected Submissions
- Tip on Assembling the Camera Stand
- Steps for Adding Open CV
- Steps for Color Sorting
- Steps for Finding the Center of the Object
- Saving Images and Reopening Images
- Steps for Background Subtraction
- Steps for Homogenous Coordinate Transformation Between Camera and Base

# Expected Demonstrations

# Expected Demonstrations

This is a **non-in-lab** demonstration lab.

The demonstration will be handled with the submission screen captures at the different stages of this lab.

- You will show you can sort objects by color.
- You will show that you can find the center of each colored object captured by the camera.
- You will show you can do background subtraction.
- You will show that you can convert from pixels to centimeters and do the homogenous transformation from the camera to the base frame.

# Expected Submissions

# Expected Submissions

A document that has the following images.

- Four images showing your pre-colored sorted image and the Red, Blue, and Green sorted images with a title that includes your last name and what it is you are showing. (i.e. - Nichols-Red Only)
- Three images showing a center mark for each of the Red, Blue, and Green objects with a title that includes your last name and what it is you are showing. (i.e. - Nichols-Center of Blue)

# Expected Submissions

- Two images showing the frame image of the pre-background subtraction and post-background subtraction with a title that includes your last name and what it is you are showing. (i.e. - Nichols-Subtraction to Find Object)



# Expected Submissions

- Three captured images showing
  1. The object, the base frame location, and the calculated center location.
  2. The computed measurement (in centimeters) within the camera image workspace.
  3. The computed measurement (in centimeters) within the base frame.


with a title for each image that **includes** your last name and what you are showing. (i.e. - Nichols-Location of the Object Relative to Base Frame)

# Tip on Assembling the Camera Stand

# Tip on Assembling the Camera Stand

You will need

- Long plywood arm
- Short plywood arm
- 3D printed mounting base bracket
- 2-piece, 3D printed, elbow
- 2-piece, 3D printed, camera mounting bracket
- 4 - M3 x 20 mm screws with nuts



# Tip on Assembling the Camera Stand


You will need

- USB web camera - disassembled
- 4 - M3 x 10mm screws and nuts (from the provided kit)
- Robotic base



# Tip on Assembling the Camera Stand

- Prep the lower section by inserting the long plywood arm into the slot of the 3D mounting base bracket and hold the two together with a M3 x 20 mm screw and nut.
- Prep the upper section by sandwiching the short plywood arm with the elbow on one end and the camera mounting bracket.



# Tip on Assembling the Camera Stand

With the upper section, **note** how the elbow and the cup of the camera mounting bracket are **orientated**.





# Tip on Assembling the Camera Stand

- With the camera clip screw removed so that there is a clip, a small screw, and a plastic disk are free from the rest of the camera.
- Insert the post on the camera up through the hole of the 3D-printed camera mount so that it sticks up into the concaved disk, as shown here.



# Tip on Assembling the Camera Stand

- Now place and align the plastic disk back onto the camera's post. There are flat spots that will lock their position together.






# Tip on Assembling the Camera Stand

- Re-attach the small screw onto the camera's post to hold the disk. **Do not over-tighten.** You want the screw tight enough to keep the camera held in position but not so tight to prevent positioning of the camera or damaging the plastic that has the screw.
- Once the screw is re-inserted. Do not remove.




# Tip on Assembling the Camera Stand

With the lower and upper sections assembled, this is a state where you can easily set up or store the camera stand.



# Tip on Assembling the Camera Stand


When ready to use, connect the two sections together and wrap the USB cable around the arm pieces.



# Tip on Assembling the Camera Stand


To secure the camera stand to the base, use four M3 x 10 mm screws and nuts in the four holes in the upper left corner of the base plate.

The image shown here is without the assembled stand, so that is easier to show how to attach it.



# Tip on Assembling the Camera Stand

If assembled and mounted to the base plate your setup will look similar to what is shown here.



# Steps for Adding Open CV via PIP





# Steps for Adding Open CV

- Open Command Line (cmd) or Terminal
- Type “python –version” and hit enter/return
  - It should return the version of Python loaded on the computer
- Type “pip install opencv-python” for Main modules package
- or type “pip install opencv-contrib-python” for the Full package (contains both main modules and contrib/extra modules)


```
PS C:\Users\kwnicho> pip install opencv-python
Collecting opencv-python
  Using cached opencv_python-4.10.0.84-cp37-abi3-win_amd64.whl.metadata (20 kB)
Requirement already satisfied: numpy>=1.21.2 in c:\users\kwnicho\appdata\local\programs\python\python3
12\lib\site-packages (from opencv-python) (2.0.0)
Using cached opencv_python-4.10.0.84-cp37-abi3-win_amd64.whl (38.8 MB)
Installing collected packages: opencv-python
Successfully installed opencv-python-4.10.0.84
```

# Steps for Adding Open CV

Now, to check the install of OpenCV

- Open IDLE Python and in the IDLE Shell
- type “import numpy as np” because OpenCV uses part of NumPy
- On the next line, type “import cv2 as cv2”

If you get no errors, then OpenCV has successfully been installed.


A screenshot of the IDLE Shell 3.12.3 window. The title bar says "IDLE Shell 3.12.3". The menu bar includes "File", "Edit", "Shell", "Debug", "Options", "Window", and "Help". The shell area shows the following text: "Python 3.12.3 (tags/v3.12.3:f6650f9, Apr 9 2024, 14:05:25) [MSC v.1938 64 bit (AMD64)] on win32", "Type 'help', 'copyright', 'credits' or 'license()' for more information.", and three lines of code: ">>> import numpy as np", ">>> import cv2 as cv2", and ">>>".

```
Python 3.12.3 (tags/v3.12.3:f6650f9, Apr 9 2024, 14:05:25) [MSC v.1938 64 bit (AMD64)] on win32
Type "help", "copyright", "credits" or "license()" for more information.
>>> import numpy as np
>>> import cv2 as cv2
>>>
```



# Steps for Adding Open CV

Let start with some basic code.

A screenshot of a Python IDE window titled "EGR\_455\_Lab08-Basic\_Camera.py - C:/Users/kwnicho/ASU Dropbox/Kevin Nichols/Robotics/0...". The window has a menu bar with "File", "Edit", "Format", "Run", "Options", "Window", and "Help". The code is written in a light blue font on a white background. It imports numpy and cv2, then uses cv2.VideoCapture(0) to capture video from the default camera. A while loop reads frames and displays them in a window titled "LastName-Frame". The loop is broken by the 'esc' key (ASCII 27). Finally, cv2.destroyAllWindows() is called to close the windows.

```
import numpy as np
import cv2

cap = cv2.VideoCapture(0) ##Set a variable to hold the video from camera #? 0,1,2

while (1):
    _,frame = cap.read()

    ## to show frame picture in a window with a title
    cv2.imshow('LastName-Frame',frame)

    ## a way to break from the loop
    k = cv2.waitKey(5) ## the number is the ms delay to check if

    ## the number '27' is the ASCII control character value for the esc key
    if k == 27:
        break

cv2.destroyAllWindows() ## to close windows python opened
```

# Steps for Adding Open CV

Run this basic starting point code.

- If you do not get the camera you want, change the number within the parentheses of “VideoCapture.” Depending on the number of camera connected or part of the computer will determine the range in numbers. (i.e. a built-in camera and USB camera means there are two choices, 0 or 1)
- If the camera is out of focus, so web camera can have there focus adjusted by turning the lens slightly.


# Steps for Color Sorting



# Steps for Color Sorting

Now, adjust the code to sort and display the results.

When you run the code, to exit the infinite for loop, press the “esc” key.



```
EGR_455_Lab08-Basic_Camera.py - C:/Users/kwnicho/ASU Dropbox/Kevin Nichols/Robotics/...
File Edit Format Run Options Window Help

import numpy as np
import cv2

cap = cv2.VideoCapture(0)

while (1):
    _, frame = cap.read()

    red = frame[:, :, 2] ## all the row, all the colmuns, the third layer
    green = frame[:, :, 1] ## all the row, all the colmuns, the second layer
    blue = frame[:, :, 0] ## all the row, all the colmuns, the first layer

    cv2.imshow('LastName-RGB', frame)
    cv2.imshow('LastName-Red Layer', red)
    cv2.imshow('LastName-Green Layer', green)
    cv2.imshow('LastName-Blue Layer', blue)

    ## a way to break from the loop
    k = cv2.waitKey(5) ## the number is the ms delay to check if

    ## the number '27' is the ASCII control character value for the esc key
    if k == 27:
        break

cv2.destroyAllWindows() ## to close windows python opened
```

# Steps for Color Sorting

Notice that you will have on each color layer there is some amount of each colored object. To get it so that you have only one color without some of the other colors, you will need to do what is called image subtraction.

Return to the Python code and modify it so you do color subtraction to find Red Only.

# Steps for Color Sorting

```
*EGR_455_Lab08-Basic_Camera.py - C:/Users/kwnicho/ASU Dropbox/Kevin Nichols/Robotics...
File Edit Format Run Options Window Help

cap = cv2.VideoCapture(0)

while (1):
    _,frame = cap.read()

    ## add np.matrix to ensure they are treated as matrices
    red = np.matrix(frame[:, :, 2])
    green = np.matrix(frame[:, :, 1])
    blue = np.matrix(frame[:, :, 0])

    ## make value a 16 bit value that can be positive or negative
    red_only = np.int16(red) - np.int16(green) - np.int16(blue)

    ## to numbers to achieve valid matrix ranging from 0 to 255
    red_only[red_only < 0] = 0 ## sets numbers lower than zero to zero
    red_only[red_only > 255] = 255 ## sets numbers greater than 255 to 255

    red_only = np.uint8(red_only) ## to ensure red_only is a unsigned interger

    cv2.imshow('LastName-RGB', frame)
    cv2.imshow('LastName-Red Layer', red)
    cv2.imshow('LastName-Green Layer', green)
    cv2.imshow('LastName-Blue Layer', blue)

    cv2.imshow('LastName-Red Only', red_only)

    ## a way to break from the loop
    k = cv2.waitKey(5) ## the number is the ms delay to check if

    ## the number '27' is the ASCII control character value for the esc key
    if k == 27:
        break

cv2.destroyAllWindows() ## to close windows python opened
```

# Steps for Color Sorting

Now when you run the code, the “Red Only” image should show a bright white where the red object is and everything else is black.

Go back and add code to be able to show the blue and green only.




Image is of the red only with the upcoming finding the center of red object.

# Steps for Finding the Center of the Object



# Steps for Finding the Center of the Object

The following additional code will find the center of the red only. The center in the column direction of the image is also the 'X' pixel value and the center in the row direction is the 'Y' in units of pixels.

```
27
28     ## how to find the center of red object in 'X' of the camera image
29     column_sums = np.matrix(np.sum(red_only,0))##'0' to sum the columns
30     column_numbers = np.matrix(np.arange(640))
31     column_mult = np.multiply(column_sums,column_numbers)#element wise multiptation
32     column_total = np.sum(column_mult)
33     total_total = np.sum(np.sum(red_only))# sum of all values in the image
34     red_column_location = column_total/total_total
35
36     print('Red column ("x") location: ',red_column_location)
37
38     ## how to find the center of red object in 'X' of the camera image
39     row_sums = np.matrix(np.sum(red_only,1))
40     row_sums = row_sums.transpose()
41     row_numbers = np.matrix(np.arange(480))
42     row_mult = np.multiply(row_sums,row_numbers)
43     row_total = np.sum(row_mult)
44     red_row_location = row_total/total_total
45
46     print('Red row ("Y") location: ',red_row_location)
47     red_only = np.uint8(red_only) # to ensure red_only is a unsigned interger
48
```

# Steps for Finding the Center of the Object

When you run this code and move a red object to the left of the camera's frame, the printed value will get smaller—approaching zero.

When the red object is moved to the right of the camera's frame, the printed value will get larger—approaching the maximum value of 640.

Use this to modify your code to get the centers of also the blue and green location.

# Saving Images and Reopening Images


# Saving Images and Reopening Images

To help capture the different images needed for submission, you might want to reopen the image or save it with text. Use the following code to do both.

```
EGR_455_Lab08-Camera_Color_Sorting(full).py - C:\Users\kwnicho\ASU Dropbox\Kevin Nichols\Robotics\03 -
File Edit Format Run Options Window Help
1 import numpy as np
2 import cv2
3 import os
4
5 cap = cv2.VideoCapture(1)
6
7 while (1):
8     _, frame = cap.read()
9
10     ## add np.matrix to ensure they are treated as matrices
```

```
146 k = cv2.waitKey(5) ## the number is the ms delay to check if
147
148 ## the number '27' is the ASCII control character value for the esc key
149 if k == 27:
150     break
151
152 ## out of "for" loop by removing tab indent
153 cv2.destroyAllWindows() ## to close windows python opened
154
155 ## Draw the "cross hairs" across the "frame" image as a form of verification of location
156 frame = cv2.line(frame, (red_x_location, 0), (red_x_location, 480), (0,0,255), thickness)
157 frame = cv2.line(frame, (0, red_y_location), (640, red_y_location), (0,0,255), thickness)
158 frame = cv2.line(frame, (blue_x_location, 0), (blue_x_location, 480), (255,0,0), thickness)
159 frame = cv2.line(frame, (0, blue_y_location), (640, blue_y_location), (255,0,0), thickness)
160 frame = cv2.line(frame, (green_x_location, 0), (green_x_location, 480), (0,255,0), thickness)
161 frame = cv2.line(frame, (0, green_y_location), (640, green_y_location), (0,255,0), thickness)
162 print('Red image size: ', np.shape(red_only))
163
164 ## Option to re-open images windows to review set position or to capture
165 cv2.imshow('LastName-RGB', frame)
166 cv2.imshow('LastName-Red Only', red_only)
167
168 ## Option to Save images
169 ## Image directory (if you want a select location, otherwise
170 ## it is save to the location of the Python code)
171 directory = r'C:\Users\kwnicho\Desktop\PythonImages'
172 os.chdir(directory)
173
174 ## Filename
175 filename = 'LastName-Red Only w location.jpg'
176
177 ## Using cv2.imwrite() method to save image
178 font_color = (255,255,255)
179 font = cv2.FONT_HERSHEY_SIMPLEX
180 font_size = 0.8
181 font_thickness = 2
182 red_text = 'LastName-Red Only w location'
183 blue_text = 'LastName-Blue Only w location'
184 green_text = 'LastName-Green Only w location'
185 rgb_text = 'LastName-RGB w location'
186 x,y = 10,20
187
188 red_only = cv2.putText(red_only, red_text, (x,y), font, font_size, font_color, font_thickness)
189 blue_only = cv2.putText(blue_only, blue_text, (x,y), font, font_size, font_color, font_thickness)
190 green_only = cv2.putText(green_only, green_text, (x,y), font, font_size, font_color, font_thickness)
191 frame = cv2.putText(frame, rgb_text, (x,y), font, font_size, (0,0,0), font_thickness)
192
193 cv2.imwrite(filename, red_only)
194 cv2.imwrite('LastName-RGB w location.jpg', frame)
195 cv2.imwrite('LastName-Blue Only w location.jpg', blue_only)
196 cv2.imwrite('LastName-Green Only w location.jpg', green_only)
197
```

# Saving Images and Reopening Images




# Steps for Background Subtraction

# Steps for Background Subtraction

Start by either copying or creating a new python code file.

I will be naming this file something like background\_subtraction.

Then edit the “while” loop as shown.

A screenshot of a Python IDE window titled "EGR\_455\_Lab08-Camer\_Background\_Subtraction.py". The window has a menu bar with "File", "Edit", "Format", "Run", "Options", "Window", and "Help". The code is as follows:

```
1 import numpy as np
2 import cv2
3
4 cap = cv2.VideoCapture(1)
5
6 while (1):
7     _, frame = cap.read()
8
9     ## converting first image from RGB to gray scale
10    gray_image_1 = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
11
12    cv2.imshow('background', gray_image_1)
13    k=cv2.waitKey(5)
14    if k == 27:
15        break
16
```

# Steps for Background Subtraction

Now that you have a background image that is captured when you hit the “esc” key, copy or add the following second “while” loop.

This loop capture a foreground image and create a difference image.

```
15         break
16
17     while (1):
18         _, frame = cap.read()
19
20         ## converting first image from RGB to gray scale
21         gray_image_2 = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
22
23         cv2.imshow('foreground', gray_image_2)
24
25         # To find the difference between the two ( Note: need to ensure values are
26         # signed appropriately and are matrices before subtracting)
27         ## since the object could be light or dark, we will take the absolute value of the difference
28         Difference = np.absolute(np.matrix(np.int16(gray_image_1)) - np.matrix(np.int16(gray_image_2)))
29
30         ## 'cleaning' the numbers to achieve valid image matrix ranging from 0 to 255
31         Difference[Difference > 255] = 255 ## sets numbers greater than 255 to 255
32         #Note: Do not need to address the negative values because that was handled with the absolute
33
34         ## Now to make the Difference matrix an unsigned 8 bit integer
35         Difference = np.uint8(Difference)
36
37         cv2.imshow('difference', Difference)
38
39         k = cv2.waitKey(5)
40         if k == 27:
41             break
42
```



# Steps for Background Subtraction


After the user exist out of the second “while,” add the code to find the center of the object.

```
41         break
42
43     ## Now to find the center of the object in 'X' dimension of the camera image
44     column_sums = np.matrix(np.sum(Difference,0))##'0' to sum the columns
45     column_numbers = np.matrix(np.arange(640))
46     column_mult = np.multiply(column_sums,column_numbers)#element wise multiplication
47     column_total = np.sum(column_mult)
48     total_total = np.sum(np.sum(Difference))# sum of all values in the image
49     difference_column_location = column_total/total_total
50
51     print('Object column ("X") location: ',difference_column_location)
52
53     ## how to find the center of the object in 'Y' of the camera image
54     row_sums = np.matrix(np.sum(Difference,1))
55     row_sums = row_sums.transpose()
56     row_numbers = np.matrix(np.arange(480))
57     row_mult = np.multiply(row_sums,row_numbers)
58     row_total = np.sum(row_mult)
59     difference_row_location = row_total/total_total
60
61     print('Object row ("Y") location: ',difference_row_location)
62
63     #####
64     # Draw the "cross hairs" across "Difference" image as a form of verification of location
65     # Line color in BGR code
66     color = (255, 255, 255)# white
67     # Line thickness in pixels
68     thickness = 1
69
70     # formatting the found locations so that it works with draw line
71     diff_x_location = np.uint16(difference_column_location)
72     diff_y_location = np.uint16(difference_row_location)
73
74     # First line is the vertical line and the second is the horizontal
75     Difference = cv2.line(Difference, (diff_x_location, 0), (diff_x_location, 480), color, thickness)
76     Difference = cv2.line(Difference, (0, diff_y_location), (640, diff_y_location), color, thickness)
77
78     cv2.imshow('difference',Difference)
79
80
```

# Steps for Background Subtraction


- With the base cleared of objects, run a test of the code module.
- The first shown is the background image, which should look something like this in a gray scale.
- When you have a steady image, hit “esc” to move forward in the code.

\*\* While running, try to keep the camera still to prevent a shaky image and poor results.



# Steps for Background Subtraction


Now place a object into view. Notice the difference image still shows the base's grid marking under the object. There is also some base line still showing.



# Steps for Background Subtraction

Now hit “esc” again to break out of the second “while” loop and see the results of finding the center of the object.

Now notice it is not accurately centered on the object.



# Steps for Background Subtraction

To fix this, let us now add the method of “Thresholding” to the code/module to convert the image from a gray scale image to a black and white image.

Added

```
EGR_455_Lab08-Camer_Background_Subtraction.py - C:/Users/kwnicho/ASU Dropbox/Kevin Nichols/Robotics/03 - Robotics - Labs/Lab Codes/Python Codes/EGR_455_Lab08-C...
File Edit Format Run Options Window
31 Difference[Difference > 255] = 255 ## sets numbers greater than 255 to 255
32 #Note: Do not need to address the negative values because that was handled with the absolute
33
34 ## Now to make the Difference matrix an unsigned 8 bit integer
35 Difference = np.uint8(Difference)
36 Saved_Diff = Difference
37 cv2.imshow('difference', Saved_Diff)
38
39 ##Thresholding
40 BW=Difference
41 BW[BW<=100]=0 #have to do this first to prevent problems by the following step
42 BW[BW>100]=255
43
44 ## Now to find the center of the object in 'X' dimension of the camera image
45 column_sums = np.matrix(np.sum(BW,0))##'0' to sum the columns
46 column_numbers = np.matrix(np.arange(640))
47 column_mult = np.multiply(column_sums,column_numbers)#element wise multiplication
48 column_total = np.sum(column_mult)
49 total_total = np.sum(np.sum(BW))# sum of all values in the image
50 BW_column_location = column_total/total_total
51 BW_column_location = np.nan_to_num(BW_column_location, nan=0)
52
53 print('Object column ("X") location: ',BW_column_location)
54
55 ## how to find the center of the object in 'Y' of the camera image
56 row_sums = np.matrix(np.sum(BW,1))##'1' to sum the rows
57 row_sums = row_sums.transpose()
58 row_numbers = np.matrix(np.arange(480))
59 row_mult = np.multiply(row_sums,row_numbers)
60 row_total = np.sum(row_mult)
61 BW_row_location = row_total/total_total
62 BW_row_location = np.nan_to_num(BW_row_location, nan=0)
63
64 print('Object row ("Y") location: ',BW_row_location)
65
66 #####
67 # Draw the "cross hairs" across "foreground" image as a form of verification of location
68 # Line color in BGR code
69 color = (255,255,255)# white
70 # Line thickness in pixels
71 thickness = 1
72
73 # formatting the found locations so that it works with draw line
74 diff_x_location = np.uint16(BW_column_location)
75 diff_y_location = np.uint16(BW_row_location)
76
77 # First line is the vertical line and the second is the horizontal
78 BW = cv2.line(BW, (diff_x_location, 0), (diff_x_location, 480), color, thickness)
79 BW = cv2.line(BW, (0, diff_y_location), (640, diff_y_location), color, thickness)
80
81 cv2.imshow('Difference w/ Center & Threshold',BW)
82
```

Changed  
for now  
BW image

# Steps for Background Subtraction

To fix this, let us now add the method of “Thresholding” to the code/module to convert the image from a gray scale image to a black and white image.

Changed for now BW row and Column location and draw lines on the BW image

```
EGR_455_Lab08-Camer_Background_Subtraction.py - C:/Users/kwnicho/ASU Dropbox/Kevin Nichols/Robotics/03 - Robotics - Labs/Lab Codes/Python Codes/EGR_455_Lab08-C...
File Edit Format Run
46 column_numbers = np.matrix(np.arange(640))
47 column_mult = np.multiply(column_sums,column_numbers)#element wise multiptation
48 column_total = np.sum(column_mult)
49 total_total = np.sum(np.sum(BW))# sum of all values in the image
50 BW_column_location = column_total/total_total
51 BW_column_location = np.nan_to_num(BW_column_location, nan=0)
52
53 print('Object column ("X") location: ',BW_column_location)
54
55 ## how to find the center of the object in 'Y' of the camera image
56 row_sums = np.matrix(np.sum(BW,1))##'1' to sum the rows
57 row_sums = row_sums.transpose()
58 row_numbers = np.matrix(np.arange(480))
59 row_mult = np.multiply(row_sums,row_numbers)
60 row_total = np.sum(row_mult)
61 BW_row_location = row_total/total_total
62 BW_row_location = np.nan_to_num(BW_row_location, nan=0)
63
64 print('Object row ("Y") location: ',BW_row_location)
65
66 #####
67 # Draw the "cross hairs" across "foreground" image as a form of verification of location
68 # Line color in BGR code
69 color = (255,255,255)# white
70 # Line thickness in pixels
71 thickness = 1
72
73 # formatting the found locations so that it works with draw line
74 diff_x_location = np.uint16(BW_column_location)
75 diff_y_location = np.uint16(BW_row_location)
76
77 # First line is the vertical line and the second is the horizontal
78 BW = cv2.line(BW, (diff_x_location, 0), (diff_x_location, 480), color, thickness)
79 BW = cv2.line(BW, (0, diff_y_location), (640, diff_y_location), color, thickness)
80
81 cv2.imshow('Difference w/ Center & Threshold',BW)
82
83 k=cv2.waitKey(5)
84 if k == 27:
85     break
86
87 ## out of "for" loop by removing tab indent
```






# Steps for Background Subtraction

Now when you run the module/code you will have results similar to these.



# Steps for Background Subtraction


Or like this with a M3 nut from your kit.






# Steps for Background Subtraction

To save the difference image without Tredholding.  
I had to save and then later read the image back in.



```
39
40     ## Now to make the Difference matrix an unsigned 8 bit interger
41     Difference = np.uint8(Difference)
42     Saved_Diff = Difference
43     cv2.imwrite('LastName-Difference.jpg', Saved_Diff)
44     cv2.imshow('difference', Saved_Diff)
45
46     ##Thresholding
47     BWDifference
```

The other images were  
handle similar to the Color  
Sorting saving of images.



```
95     if k == 27:
96         break
97
98     ## out of "for" loop by removing tab indent
99     cv2.destroyAllWindows() ## to close windows python opened
100
101     Saved_Diff = cv2.imread('LastName-Difference.jpg')
102
103     Saved_Diff = cv2.line(Saved_Diff, (diff_x_location, 0), (diff_x_location, 480), color, th
104     Saved_Diff = cv2.line(Saved_Diff, (0, diff_y_location), (640, diff_y_location), color, th
105
106     gray_image_2 = cv2.line(gray_image_2, (diff_x_location, 0), (diff_x_location, 480), (0,0,
107     foreground = cv2.line(gray_image_2, (0, diff_y_location), (640, diff_y_location), (0,0,0)
```

# Steps for Homogenous Coordinate Transformation Between Camera and Base

# Homogenous Coordinate Transformation

## Converting from Pixels to Centimeters


Till now, the 'X' and 'Y' location has been in units of pixels. You will need these coordinates in units of centimeters to be able to complete the Homogenous Transformation.

Start by saving your Background subtraction module/code as something like Camera\_Pixel\_to\_Centimeters.

# Homogenous Coordinate Transformation

## Converting from Pixels to Centimeters

Run the newly saved module/code. During the background stage section, measure across the viewable window. Aligning one end so the zero is just at the edge the ruler is parallel to the top as shown here. Note where the other edge goes out of view and get that measurement. **This time** I got a measurement of about 21.6 cm.



# Homogenous Coordinate Transformation

## Converting from Pixels to Centimeters

Now with the measure, you can add the following couple of lines of code to the module.



```
EGR_455_Lab08-Camer_Pixel_2_CM.py - C:/Users/kwnicho/ASU Dropbox/Kevin Nichols/Robotics/03 - Robotics - Labs/Lab Codes/Python Code
File Edit Format Run Options Window Help
1 import numpy as np
2 import cv2
3 import os
4
5 directory = r'C:\Users\kwnicho\Desktop\PythonImages'
6 os.chdir(directory)
7
8 cap = cv2.VideoCapture(1)
9
10 cm_to_pixel=21.6/640 #if measured across image
11
12 # While loop to capture background image
13 while (1):
14     _,frame = cap.read()
15
16     ## converting first image from RGB to gray scale
17     gray_image = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
18
19     column_numbers = np.matrix(np.arange(640))
20     column_mult = np.multiply(column_numbers,column_numbers)#element wise multiptation
21     column_total = np.sum(column_mult)
22     total_total = np.sum(np.sum(BW))# sum of all values in the image
23     BW_column_location = column_total/total_total
24     BW_column_location = np.nan_to_num(BW_column_location, nan=0)
25
26     { X_Location = BW_column_location*cm_to_pixel
27       print('Object "X" location (cm): ',X_Location)
28     }
29
30     ## how to find the center of the object in 'Y' of the camera image
31     row_sums = np.matrix(np.sum(BW,1))##'1' to sum the rows
32     row_sums = row_sums.transpose()
33     row_numbers = np.matrix(np.arange(480))
34     row_mult = np.multiply(row_sums,row_numbers)
35     row_total = np.sum(row_mult)
36     BW_row_location = row_total/total_total
37     BW_row_location = np.nan_to_num(BW_row_location, nan=0)
38
39     { Y_Location = BW_row_location*cm_to_pixel
40       print('Object "Y" location (cm): ',Y_Location)
41     }
42
43     #####
44     # Draw the "cross hairs" across "foreground" image as a form of verification of locat
```

# Homogenous Coordinate Transformation

## Converting from Pixels to Centimeters


Additionally, you will add it so the measurements are also printed on the image by adding the following lines of code.

```
*EGR_455_Lab08-Camer_Pixel_2_CM.py - C:/Users/kwnicho/ASU Dropbox/Kevin Nichols/Robotics/03 - Robotics - Labs/Lab Codes/Python Codes/EGR_455_Lab08-Camer...
File Edit Format Run Options Window Help
81 #####
82 # Draw the "cross hairs" across "foreground" image as a form of verification of location
83 # Line color in BGR code
84 color = (255,255,255) # white
85 # Line thickness in pixels
86 thickness = 1
87
88 # formatting the found locations so that it works with draw line
89 diff_x_location = np.uint16(BW_column_location)
90 diff_y_location = np.uint16(BW_row_location)
91
92 # First line is the vertical line and the second is the horizontal
93 BW = cv2.line(BW, (diff_x_location, 0), (diff_x_location, 480), color, thickness)
94 BW = cv2.line(BW, (0, diff_y_location), (640, diff_y_location), color, thickness)
95
96 foreground = cv2.line(gray_image_2, (diff_x_location, 0), (diff_x_location, 480), (0,0,0), thickness)
97 foreground = cv2.line(foreground, (0, diff_y_location), (640, diff_y_location), (0,0,0), thickness)
98
99
100 unit_Text = f"x:{X_Location}, y:{Y_Location} "
101 font = cv2.FONT_HERSHEY_SIMPLEX
102 font_size = 0.8
103 font_thickness = 2
104 x,y = 10,20
105 BW = cv2.putText(BW, unit_Text, (x,50), font, font_size, (255,255,255), font_thickness)
106
107 cv2.imshow('Difference w/ Center & Threshold',BW)
108
109 foreground = cv2.putText(foreground, unit_Text, (x,50), font, font_size, (0,0,0), font_thickness)
110
111 cv2.imshow('Foreground w/ Center & Threshold',foreground)
112
113 k=cv2.waitKey(5)
114 if k == 27:
115     break
116
```

# Homogenous Coordinate Transformation

## Converting from Pixels to Centimeters

With those changes, you should get the similar results as shown here.



LastName—Difference without Threshold

A grayscale image showing the difference between the foreground and background of the document page. The image is mostly black, with some white and gray areas indicating the difference. The text "LastName—Difference without Threshold" is overlaid in the top left corner.

LastName — BW with Center  
x:8.904, y:4.46

A binary (black and white) image showing the result of applying a threshold to the difference image. The image is mostly black, with some white areas indicating the thresholded difference. The text "LastName — BW with Center" and "x:8.904, y:4.46" is overlaid in the top left corner.

# Homogenous Coordinate Transformation

## Converting from Pixels to Centimeters

Now, if you tried to check how accurate these converted measurements are, you will find it tricky once you place a ruler into view.

I found adding the following “while” loop helpful.


```
106
107 cv2.imshow('Difference w/ Center & Threshold',BW)
108
109 foreground = cv2.putText(foreground, unit_Text, (x,50), font, font_size, (0,0,0), font_thickness)
110
111 cv2.imshow('Foreground w/ Center & Threshold',foreground)
112
113 k=cv2.waitKey(5)
114 if k == 27:
115     break
116
117 # While loop to check object measured position
118 while (1):
119     _,frame = cap.read()
120
121     ## converting first image from RGB to gray scale
122     check_image = cv2.cvtColor(frame,cv2.COLOR_BGR2GRAY)
123
124     check_image = cv2.line(check_image, (diff_x_location, 0), (diff_x_location, 480), (0,0,0), thickness)
125     check_image = cv2.line(check_image, (0, diff_y_location), (640, diff_y_location), (0,0,0), thickness)
126     check_image = cv2.putText(check_image, unit_Text, (x,y), font, font_size, (0,0,0), font_thickness)
127
128     cv2.imshow('check_image',check_image)
129     k=cv2.waitKey(5)
130     if k == 27:
131         break
132
133
134 ## out of "for" loop by removing tab indent
135 cv2.destroyAllWindows() ## to close windows python opened
```



# Homogenous Coordinate Transformation

## Converting from Pixels to Centimeters


With that third “while” loop I can now measure without the measure moving. Additionally, if I bump the object, I still have the cross-hair lines as reference.



# Homogenous Coordinate Transformation

## Setting Up the Homogenous Transformation Matrix

Now you need to set-up a Homogenous Transformation Matrix that changes the camera's 'X' and 'Y' location to a location in reference to the manipulator's base coordinate frame.




# Homogenous Coordinate Transformation

## Setting Up the Homogenous Transframation Matrix

One thing that is needed is the rotational matrix that describes the differences between the two coordinate frames.


- It will take two rotation in this set-up to get the coordinate frame orientated the same.
- First rotation can be about the 'Z' axis  $4^\circ$  to get the ' $X_0$ ' axis aligned with Camera's 'X'



# Homogenous Coordinate Transformation

## Setting Up the `Matrix

- The second rotation can be about the 'Y' axis  $180^\circ$  to get the 'X' and 'Z' axis in the same direction.



# Homogenous Coordinate Transformation

## Setting Up the Homogenous Transframation Matrix


$$R_C^0 = R_Z R_x$$

$$R_Z = \begin{bmatrix} \cos(\theta_z) & -\sin(\theta_z) & 0 \\ \sin(\theta_z) & \cos(\theta_z) & 0 \\ 0 & 0 & 1 \end{bmatrix}$$

$$\theta_z = 4^\circ$$

$$R_y = \begin{bmatrix} \cos(\theta_y) & 0 & \sin(\theta_y) \\ 0 & 1 & 0 \\ -\sin(\theta_y) & 0 & \cos(\theta_y) \end{bmatrix}$$

$$\theta_y = 180^\circ$$




# Homogenous Coordinate Transformation

## Setting Up the Homogenous Transframation Matrix

The next thing that is needed is the displacement vector.

$D_x$  = distance from the Manipulator's origin, along the X-axis to it interception of the Camera's Y-axis

$D_y$  = distance from the Manipulator's origin, along the Y-axis to it interception of the Camera's X-axis



# Homogenous Coordinate Transformation

## Setting Up the Homogenous Transframation Matrix

Take the last module code where we did the pixel to centimeter conversion and save it to something like “Homogenous.”

Now we will add this information into the top of this code module.

```
EGR_455_Lab08-Homogenous.py - C:/Users/kwnicho/ASU Dropbox/Kevin Nichols/Robotics/03 - Robotics - Labs/Lab Codes/Python Codes/EGR_455_Lab08
File Edit Format Run Options Window Help
1 import numpy as np
2 import cv2
3 import os
4
5 directory = r'C:\Users\kwnicho\Desktop\PythonImages'
6 os.chdir(directory)
7
8 cap = cv2.VideoCapture(1)
9
10 cm_to_pixel=21.6/640 #if measured across image
11
12 Theta_Z = -2 #in degrees, rotation about Z axis
13
14 Theta_Y = np.pi #or 180 degrees, rotation about Z axis
15 Theta_Z = (Theta_Z/180.0)*np.pi #Z rotation now in radians
16
17 R_z = [[np.cos(Theta_Z), -np.sin(Theta_Z), 0],[np.sin(Theta_Z), np.cos(Theta_Z), 0],[0, 0, 1]]
18 R_y = [[np.cos(Theta_Y), 0, np.sin(Theta_Y)],[0, 1, 0],[-np.sin(Theta_Y), 0, np.cos(Theta_Y)]]
19 R0_C = np.dot(R_z, R_y)
20
21 Dx = 7.4
22 Dy = -0.9
23 Dz = 0.0
24
25 D0_C=[Dx],[Dy],[Dz]]
26 H0_C = np.concatenate((R0_C,D0_C),1)
27 H0_C = np.concatenate((H0_C, [[0, 0, 0, 1]]),0)
28
29 # While loop to capture background image
30 while (1):
31     _,frame = cap.read()
32
33     ## converting first image from RGB to gray scale
34     gray_image_1 = cv2.cvtColor(frame,cv2.COLOR_BGR2GRAY)
35
```



# Homogenous Coordinate Transformation

## Setting Up the Homogenous Transformation Matrix

The next thing is to convert the camera dimensions into manipulator dimensions by adding this little bit of code in Red. I then modified the code in the green and blue to print the result.

Now, it is time to test.

Content changed

```
90 on = np.nan_to_num(BW_row_location, nan=0)
91 Y_Location = BW_row_location*cm_to_pixel
92
93 # Transform Coordinates
94 PC = [[X_Location], [Y_Location], [0], [1]]
95 P0 = np.dot(H0_C, PC)
96 X_BaseFrame = P0[0]
97 Y_BaseFrame = P0[1]
98
99 X_BaseFrame = np.round(X_BaseFrame, 3)
100 Y_BaseFrame = np.round(Y_BaseFrame, 3)
101 print('Object "X" location (cm): ', X_BaseFrame)
102 print('Object "Y" location (cm): ', Y_BaseFrame)
103
104 #####
105 # Draw the "cross hairs" across "foreground" image as a form of verification of
106 # Line color in BGR code
107 color = (255, 255, 255) # white
108 # Line thickness in pixels
109 thickness = 1
110
111 # formatting the found locations so that it works with draw line
112 diff_x_location = np.uint16(BW_column_location)
113 diff_y_location = np.uint16(BW_row_location)
114
115 # First line is the vertical line and the second is the horizontal
116 BW = cv2.line(BW, (diff_x_location, 0), (diff_x_location, 480), color, thickness)
117 BW = cv2.line(BW, (0, diff_y_location), (640, diff_y_location), color, thickness)
118
119 foreground = cv2.line(gray_image_2, (diff_x_location, 0), (diff_x_location, 480),
120 foreground = cv2.line(foreground, (0, diff_y_location), (640, diff_y_location),
121
122
123 unit_Text = f"x:{X_BaseFrame}, y:{Y_BaseFrame}"
124 font = cv2.FONT_HERSHEY_SIMPLEX
125 font_size = 0.8
126 font_thickness = 2
```

Move down and  
content changed



# Homogenous Coordinate Transformation

## Setting Up the Homogenous Transframation Matrix

